


WMS 8.4 Tutorial

Storm Drain Modeling – Storm Drain: Hydrographic Design

Learn how to run sub-basin hydrographs through a storm drain network



Objectives

Build a rational method model and compute sub-basin hydrographs. Digitize a small pipe network and define the pipe parameters. Run the rational method hydrographs through the storm drain model using the FHWA storm drain analysis engine.

Prerequisite Tutorials

- Watershed Modeling – Rational Method Interface
- Editing Elevations – Using TINs


Required Components

- Data
- Drainage
- Map
- Hydrology
- Hydrologic Models
- Storm Drain

Time

- 30-60 minutes

AQUAVEO™



1 Contents

1	Contents	2
2	Introduction.....	2
3	Objectives.....	3
4	Developing the Surface Drainage Coverage	3
4.1	Eliminating Unnecessary Stream Arcs and Nodes	3
4.2	Initializing Storm Drain Simulation	4
4.3	Assigning Stream Arcs as Gutters.....	5
4.4	Assigning Outlets as Storm Drain Inlets	5
5	Running a Rational Analysis.....	6
5.1	Defining Rational Method Basin Parameters	7
5.2	Defining Rational Method Routing Parameters	7
5.3	Computing Hydrographs	8
6	Creating the Pipe Network.....	8
6.1	Digitizing Storm Drain Pipes	8
6.2	Entering Storm Drain Parameters.....	9
6.3	Defining the Outfall and Manhole Locations	10
6.4	Linking Nodes.....	11
6.5	Assigning Elevations and Mapping Hydrographs	11
7	Saving the Simulation and Running Storm Drain.....	12

2 Introduction

Storm Drain is a hydraulic analysis and design program for storm drain and sanitary sewer systems. It was developed by the Federal Highway Administration (FHWA) with the intent of providing hydraulic engineers a quick and accurate method of designing and analyzing storm drain, sanitary sewer, and combination systems. The Storm Drain interface in WMS uses the same HYDRA program to perform calculations that is currently part of the FHWA's HYDRAIN suite of hydraulic programs.

This exercise demonstrates how to use WMS to set up a Hydrographic Drainage simulation for use with Storm Drain. We will set up drainage areas and Runoff Coefficients for a subdivision, similar to the previous chapter, but we will also specify gutter locations in the Drainage coverage. As illustrated in this exercise, the pipe network does not need to flow parallel or in the same direction as the over-lying drainage. However, there are some limitations in the way the drainage coverage is constructed in order to run a hydrographic analysis with Storm Drain. The most important limitation is that each inflow hydrograph needs to be associated with one and only one gutter at the storm drain inlet. In other words "extra" stream arcs that are not part of the gutter leading into the inlet should be deleted.

In this analysis we will generate input hydrographs using the Rational Method calculator, but it should be emphasized that any hydrologic method that produces a hydrograph can be used, or hydrographs may be entered manually.

3 Objectives

In this exercise, we will set up a hydrographic storm drain simulation for a hypothetical subdivision. The objective of this exercise is to teach you the basic steps for defining a Storm Drain input file for hydrographic analysis. These steps include the following:

1. Build the drainage basins and make adjustments for limitations in doing a hydrographic analysis
2. Perform a simple Rational Method analysis to generate input hydrographs
3. Digitize a small pipe network based on the surface drainage
4. Define the necessary parameters for the pipe network
5. Run Storm Drain (HYDRA)
6. View the solution

4 Developing the Surface Drainage Coverage

We will begin with a drainage coverage created with techniques typical to those described in earlier chapters. In order to prepare the drainage coverage for storm drain analysis we will eliminate all of the stream arcs, except those that lead into a given outlet (a storm drain inlet in this case). Having extra branching streams prevents WMS from building the storm drain input file correctly. You must decide which arc represents the primary stream (in this case a gutter) into an inlet and delete the others.

1. Close all instances of WMS
2. Open WMS
3. Switch to the *Map* module 
4. Select **File / Open** 
5. Locate the folder *C:\Program Files\WMS84\tutorial\stormhydro*
6. Open “*sdstart.map*”

4.1 Eliminating Unnecessary Stream Arcs and Nodes

Figure 4-1 shows the drainage coverage with the extra streams highlighted (arrows provide additional clarification). In order to prepare the drainage coverage correctly you will need to delete these stream arcs.




Figure 4-1: Initial drainage coverage with unnecessary stream arcs shown.

1. Select the *Select Feature Arc* tool 
2. While holding down the SHIFT key (for multi-selection) select the four arcs highlighted in Figure 4-1
3. Select the *Delete* macro  (or *Edit / Delete* or the DELETE key)
4. Select OK

You must now delete the extra nodes that were at the intersection of the arcs just deleted and the remaining arcs so that there is just a single arc entering the storm drain inlet points.

5. Select the *Select Feature Point/Node* tool 
6. While holding down the SHIFT key, select the three nodes identified by arrows in Figure 4-2 (be sure to select the point to the right of the outlet at the far right and not the point that is the outlet)




Figure 4-2: Nodes that need to be converted to vertices.

7. Select *Feature Objects / Vertex <-> Node*

4.2 Initializing Storm Drain Simulation

In order to assign the remaining stream arcs to be gutters and the outlet points as storm drain inlets we must initialize a storm drain analysis.

1. Select Storm Drain-FHWA from the Models drop-down list at the top of the screen
2. Select *Storm Drain-FHWA / New Simulation*

4.3 Assigning Stream Arcs as Gutters

1. Select the *Select Feature Arc* tool 
2. While holding down the SHIFT key, select all four stream arcs as indicated in Figure 4-3




Figure 4-3: Arcs to be selected.

3. Select *Feature Objects / Attributes*
4. Select Gutter for the Feature Arc Type
5. Choose the Atts button to define the properties of the gutters
6. Set the type to Uniform Gutter (this should be the default) and set the Manning's n to 0.015, the Roadway Cross-slope to 0.02, and the width to 2.0
7. Select OK
8. Select OK

4.4 Assigning Outlets as Storm Drain Inlets

For this analysis, two of the outlets will be defined in areas of depression (sump conditions) while the other two will have bypass flow (on grade conditions).

1. Select the *Select Feature Point/Node* tool 
2. While holding down the SHIFT key select both of the outlet points of the entire basin system, and the outlet of the isolated interior basin as indicated in Figure 4-4




Figure 4-4: Outlet points to be selected.

3. Select **Feature Objects / Attributes**
4. Set the Drainage Feature Point Type to be Storm drain inlet
5. Choose the Properties button
6. Set the Type to be Grate in sump condition, the Subtype to be Reticuline, the Width to be 2.0, the Length to be 6.0, the Inlet Perimeter to be 16.0, and the Area to be 8.5
7. Select OK
8. Select OK
9. Select one of the other two remaining outlets (this will ensure that the two selected outlets become unselected)
10. Now while holding down the SHIFT key select the remaining outlet (the one that has not yet been selected)
11. Select **Feature Objects / Attributes**
12. Set the Drainage Feature Point Type to be Storm drain inlet
13. Choose the Properties button
14. Set the Type to be Grate on grade, the Subtype to be Reticuline, the Width to be 2.0, and the Length to be 6.0
15. Select OK
16. Select OK
17. Select **Feature Objects / Compute Basin Data**
18. Select OK

5 Running a Rational Analysis

We will perform a simple Rational analysis of this subdivision and use the Rational method hydrographs as input for the hydrographic storm drain analysis. You should remember, though, that any of the hydrologic analysis models in WMS can be used, or input hydrographs may be entered manually.

1. Select the *Hydrologic Modeling* module 

2. Change the Model drop-down box located at the top of the WMS interface to Rational

5.1 Defining Rational Method Basin Parameters

1. Double-click on one of the basin icons using the *Select Basin* tool  and define the basin parameters according to Figure 5-1 and Table 5-1. Select another basin and define its parameters until all basin data is defined. For more details on defining a Rational Simulation see the chapter on Rational method analysis (Volume 2, Chapter 5).




Figure 5-1: Basin locations.

Table 5-1: Rational Method basin parameters.

Basin	C	I (in/hr)	Tc (min)
1	0.10	2.4	22
2	0.15	2.7	18
3	0.15	3.1	12
4	0.20	3.8	07

2. Select OK in the Rational Method dialog

5.2 Defining Rational Method Routing Parameters

1. Define the intensity and routing time for the four confluence points connected to the basins according to Table 5-2. As with basins, reach data are entered by double-clicking on the yellow outlet icons using the *Select Outlet* tool .

Table 5-2: Rational Method routing parameters.

Outlet	Routing Lag (min)	I (in/hr)
1	5	2.4
2	4	1.9
3	0	1.7
4	0	3.8

2. Select OK in the Rational Method dialog

5.3 Computing Hydrographs

1. Double-click on the outlet for the isolated interior basin (the outlet of basin 4 in Figure 5-1)
2. Choose the Compute Hydrographs button at the bottom of the Outlet column
3. Select Done (use the default settings for the Rational method hydrograph)
4. Select OK
5. Double-click on the outlet for the entire watershed (the outlet of basin 3 in Figure 5-1)
6. Choose the Compute Hydrographs button at the bottom of the Outlet column
7. Select Done (use the default settings for the Rational method hydrograph)
8. Select OK

At this point you should have hydrographs defined for the drainage coverage. These hydrographs will be used as input to the storm drain problem.

6 Creating the Pipe Network

You will now create a storm drain pipe network that connects the isolated interior basin to the others and exits west of the watershed outlet. You will do this by creating a Storm Drain coverage and then digitizing the storm drain pipes using the *Create Feature Arc* tool.

6.1 Digitizing Storm Drain Pipes



1. Right-click on the Coverages folder in the Project Explorer
2. Select *New Coverage*
3. Change the Coverage type to Storm Drain-FHWA
4. Select OK
5. Select the *Create Feature Arc* tool 
6. Beginning at a point just to the left (west) of the outlet of the watershed (basin 3) begin a pipe network segment and end it by double-clicking on top of the outlet of basin 3.
7. Now complete the storm drain network by creating the pipe segments from downstream to upstream between basin 3 and basin 2, basin 2 and basin 1, and a connection from the pipe between basin 2 and basin 1 to the outlet of basin 4. Be sure that feature nodes (segment endings) are created by double-clicking to end the arc to correspond with the storm drain inlets of the drainage coverage. Your storm drain coverage should look similar to Figure 6-1.




Figure 6-1: View of the Storm Drain coverage.


6.2 Entering Storm Drain Parameters

1. Select *Storm Drain-FHWA / Job Control*
2. Set the title to: Hydrographic Storm Drain Analysis
3. Set the Criteria Switch to 3 - Storm (Hydrographic) only
4. Set the timestep to 2
5. Set the Units to English
6. Choose the Pipe Data Properties button
7. Set the values according to Figure 6-2

Figure 6-2: Pipe properties.

8. Select OK
9. Select OK

6.3 Defining the Outfall and Manhole Locations



1. Choose the *Select Feature Point/Node* tool 
2. Double-click on the node to the left of the drainage basin
3. Set the Node Type as Outfall
4. Select OK
5. Use the SHIFT key to select the four nodes of the storm drain coverage that correspond to the four storm drain inlets (manholes) of the drainage coverage as shown in Figure 6-3
6. Select *Feature Objects / Attributes*
7. Set the Node Type as Access Hole
8. Set the width to be 4.0
9. Select OK

You could define each manhole separately by double-clicking on the node and setting the node type and manhole width, but it is more efficient to define them all at once. At this point you should have one outfall node, four manhole nodes, and a single pipe junction in

your storm drain coverage as identified in Figure 6-3. If this is not the way your storm drain coverage is set up, then correct it now.




Figure 6-3: The correct setup of the Storm Drain coverage.

6.4 Linking Nodes

To properly portray the relationship between the drainage coverage and the storm drain coverage, we need to explicitly define links between corresponding nodes.

1. Select *Storm Drain-FHWA / Link Nodes*
2. Change the tolerance to 25
3. Click the Auto Link button. This should link the four storm drain inlet nodes of the drainage coverage to the four manholes of the storm drain coverage. If not, increase the tolerance by an increment of 5 and select the Auto Link button until the four node pairs are linked.
4. Select OK

6.5 Assigning Elevations and Mapping Hydrographs

We also need to assign elevations to all the nodes in the Storm Drain and Drainage coverages. Elevations can either be defined manually, or with the use of a background TIN or DEM. In this exercise we will manually define them.

1. Toggle the display of the Drainage coverage off in the Project Explorer
2. Choose the *Select Feature Point/Node* tool 
3. Set the elevations of the nodes in the Storm Drain coverage according to the values given in Figure 6-4. To set an elevation, select the node and change the elevation in the Feature Point Z edit field in the Properties window on the right of the WMS interface and press Enter.



Figure 6-4: Node elevations for the storm drain pipes.



4. Toggle the Drainage coverage on and the Storm Drain-FHWA coverage off in the Project Explorer
5. Select the Drainage coverage in the Project Explorer so that it is the active coverage
6. Select and set the elevations of all the nodes connected to the gutter arcs according to Figure 6-5




Figure 6-5: Node elevations for the gutters.



With Drainage and Storm Drain nodes linked, and elevations assigned to our pipes and gutters, we are ready to save and run the Storm Drain model.

7. Set Storm Drain-FHWA as the active coverage in the Project Explorer
8. Select *Storm Drain-FHWA / Map Hydrographs*

7 Saving the Simulation and Running Storm Drain

1. Select *File / Save As*
2. Make sure the Save as type filter is set to WMS XMDF Project Files (*.wms)
3. Enter “wms_storm_hyd” as the File name
4. Select Save
5. Select *Storm Drain-FHWA / Save Simulation*
6. Save the file as “wms_st_h”
7. Select *Storm Drain-FHWA / Run Simulation*

8. Set the input file name to “wms_st_h.hda” and the output file name to “wms_st_h.lst”

The input and output file name prefixes can be up to 8 characters in length. If you enter a name longer than 8 characters, it is truncated to 8 characters when Storm Drain writes the file. Further, no directory in the path to the files can be longer than 8 characters.

9. Select OK
10. Once Storm Drain (HYDRA) has finished running, select Close
11. Select OK
12. Select **File / Edit File**
13. Open “wms_st_h.lst”
14. Select OK to open the file with Notepad

By browsing through this file, you will see all of the parameters calculated by the Storm Drain model, such as recommended pipe diameters, pipe invert elevations, flows, velocities, and hydraulic grade line computations.

15. Close Notepad